

Technische Universität Graz

Transport



Technische Universität Graz

Transport phenomena

Bloch waves Crystal momentum Group velocity

Boltzmann equation
Electrical conductivity
Thermal conductivity
Hall effect
Peltier effect
Seebeck effect
Ettingshausen effect
Nerst effect

• Transport

- Thermoelectric effects
- Crystal momentum
- Boltzmann equation
- Relaxation time approximation
- Current densities
- Electrochemical potential
- Electrical conductivity
- Thermoelectric currents
- Seebeck effect
- Hall effect
- Nernst effect
- Free-electron model
 - Electrical conductivity
 - Electrical contribution to the thermal conductivity
 - Wiedemann–Franz law
- Transport in 1-D crystals
 - Current of Bloch waves in 1-D

Bloch waves

Any wave function: $\psi(\vec{r}) = \sum_{\vec{k}} c_{\vec{k}} e^{i\vec{k}\cdot\vec{r}}$

$$\psi(ec{r}) = \sum_{ec{k} \in ext{1BZ}} \sum_{ec{G}} c_{ec{k} + ec{G}} e^{i(ec{k} + ec{G}) \cdot ec{r}}$$

Bloch wave: $\psi_{\vec{k}}(\vec{r}) = e^{i\vec{k}\cdot\vec{r}} \sum_{\vec{G}} c_{\vec{k}+\vec{G}} e^{i\vec{G}\cdot\vec{r}} = e^{i\vec{k}\cdot\vec{r}} u_{\vec{k}}(\vec{r})$

$$\psi(ec{r}) = \sum_{ec{k} \in ext{1BZ}} \psi_{ec{k}}(ec{r}).$$

$$\mathbf{T}\psi_{ec{k}}(ec{r})=e^{iec{k}\cdot(ec{r}+ec{a})}u_{ec{k}}(ec{r}+ec{a})=e^{iec{k}\cdotec{a}}e^{iec{k}\cdotec{r}}u_{ec{k}}(ec{r})=e^{iec{k}\cdotec{a}}\psi_{ec{k}}(ec{r})$$

Bloch waves are eigenfunctions of the Hamiltonian

Bloch waves in 1-D

It is instructive to consider a one-dimensional crystal at this point since the dispersion relation $E(\vec{k})$ can be readily calculated numerically in one-dimension. Consider an electron moving in a periodic potential V(x). The period of the potential is a, V(x+a) = V(x). The Schrödinger equation for this case is,


$$-rac{\hbar^2}{2m}rac{d^2\psi}{dx^2}+V(x)\psi=E\psi.$$

Quantum mechanically, the electron moves as a wave through the potential. Due to the diffraction of these waves, there are bands of energies where the electron is allowed to propagate through the potential and bands of energies where no propagating solutions are possible. The Bloch theorem states that the propagating states have the form,

$$\psi = e^{ikx}u_k(x).$$

where k is the wavenumber and $u_k(x)$ is a periodic function with periodicity a.

There is a left moving Bloch wave $\psi_- = e^{-ikx}u_{k-}$ and a right moving Bloch wave $\psi_+ = e^{ikx}u_{k+}$ for every energy. The following form calculates the Bloch waves for a potential V(x) that is specified in the interval between 0 and a. A discussion of the calculation can be found below the form.



Crystal momentum $\hbar \vec{k}$

Ehrenfest theorem:
$$i\hbar \frac{d}{dt} \langle {f A} \rangle = \langle [{f A}, {f H}]
angle$$

translation operator $T\psi(\vec{r}) = \psi(\vec{r} + \vec{a})T$

< T > is a constant of motion $i\hbar \frac{d}{dt} \langle \mathbf{T} \rangle = \langle [\mathbf{T}, \mathbf{H}_0] \rangle = 0.$ for a perfect crystal

Consider an external force $ec{F} = abla U$ $U = -F_x x - F_y y - F_z z$

$$i\hbarrac{d}{dt}\langle\mathbf{T}
angle=\langle[\mathbf{T},\mathbf{H}_{0}-F_{x}x-F_{y}y-F_{z}z]
angle.$$

Since $[\mathbf{T}, \mathbf{H}_0] = [\mathbf{H}_0, \mathbf{T}] = 0$, this is,

$$i\hbarrac{d}{dt}\langle\mathbf{T}
angle = \langle -\mathbf{T}(F_xx+F_yy+F_zz)+(F_xx+F_yy+F_zz)\mathbf{T}
angle$$

Crystal momentum

$$i\hbarrac{d}{dt}\langle\mathbf{T}
angle=\langle-\mathbf{T}(F_xx+F_yy+F_zz)+(F_xx+F_yy+F_zz)\mathbf{T}
angle.$$

Allow **T** to act on $(F_x x + F_y y + F_z z)$,

$$egin{aligned} i\hbarrac{d}{dt}\langle\mathbf{T}
angle &= \langle -(F_x(x+a_x)+F_y(y+a_y)+F_z(z+a_z))\mathbf{T}+(F_xx+F_yy+F_zz)\mathbf{T}
angle \ &= \langle -(F_xa_x+F_ya_y+F_za_z)\mathbf{T}
angle \end{aligned}$$

Here a_x , a_y , a_z are integer steps in the periodic lattice. As $(F_x a_x + F_y a_y + F_z a_z)$ is a constant,

$$i\hbarrac{d}{dt}\langle\mathbf{T}
angle=-(F_{x}a_{x}+F_{y}a_{y}+F_{z}a_{z})\langle\mathbf{T}
angle.$$

Crystal momentum

$$i\hbarrac{d}{dt}\langle\mathbf{T}
angle=-(F_{x}a_{x}+F_{y}a_{y}+F_{z}a_{z})\langle\mathbf{T}
angle.$$

For a Bloch wave $\langle \mathbf{T} \rangle = \langle e^{-i \vec{k} \cdot \vec{r}} u_{\vec{k}}^* | \mathbf{T} | e^{i \vec{k} \cdot \vec{r}} u_{\vec{k}} \rangle = e^{i \vec{k} \cdot \vec{a}} \langle e^{-i \vec{k} \cdot \vec{r}} u_{\vec{k}}^* | e^{i \vec{k} \cdot \vec{r}} u_{\vec{k}} \rangle = e^{i \vec{k} \cdot \vec{a}},$


$$i\hbarrac{d}{dt}e^{iec{k}\cdotec{a}}=-(F_xa_x+F_ya_y+F_za_z)e^{iec{k}\cdotec{a}}.$$

The external force will cause the momentum of the electron to change so \vec{k} will be time dependent. Performing the differentiation with respect to time,

$$-\hbar\left(rac{dk_x}{dt}a_x+rac{dk_y}{dt}a_y+rac{dk_z}{dt}a_z
ight)e^{iec{k}\cdotec{a}}=-(F_xa_x+F_ya_y+F_za_z)e^{iec{k}\cdotec{a}}.$$


$$\hbarrac{dec{k}}{dt}=ec{F}_{
m ext}.$$

Group velocity



https://en.wikipedia.org/wiki/Phase_velocity

Group velocity



 $\vec{F}_{ext} = \frac{\hbar^2}{\nabla^2 F(\vec{k})} \frac{d\vec{v}_g}{dt} = m^*(\vec{k}) \vec{a}_g$

Particles in a semiconductor can be thought of as free particles with an effective mass.

 $\Delta x \Delta k \sim 1$

Wave/particle nature of electrons

Usually when we think about a current flowing, we imagine the electrons as particles moving along. Really we should be thinking about how the occupation of the wave like eigenstates are changing.

When wave packets are built from the eigenstates, they move like particles with an effective mass.