



10. MOSFETs


Dec. 4, 2019

MOSFETs



n - channel

functions as a switch
 ~ 1 billion /chip



p - channel

Self-aligned fabrication

p-Si 100 wafer

Dry oxidation

SiO_2 gate oxide


p-Si

gate oxide

HfO_2

SiO_2

p-Si



photoresist

polysilicon

CVD: SiH_4 @ 580 to 650 °C


TiN (CVD)

30–70 $\mu\Omega\cdot\text{cm}$ Conductive diffusion barrier


$\text{SiO}_2/\text{HfO}_2$

p-Si






Self-aligned fabrication



Spacer

PECVD SiN_x



Spacer

Etch back to
leave only
sidewalls

SiN_x


polysilicon
gate

n+

n+

p-Si

Implant



polysilicon
gate


n+


n+

p-Si

Salicide (Self-aligned silicide)

Transition metal (Ti, Co, W) is deposited (CVD). During a high temperature step it reacts to a silicide ($TiSi_2$). No silicide is formed on nitride or oxide.





MOSFET in TCAD

CMOS

NMOS is n-channel so it should be in a p-well






Figure 26.11 Deep submicron CMOS: 200 nm gate length, 5 nm gate oxide, 70 nm junction depth; n⁺ poly for NMOS and p⁺ poly for PMOS. Shallow trench isolation on epitaxial n⁺/p⁺ wafer

Source: Fransila


MOS capacitor





Accumulation





$\rho \times 10^{-15}$
[C/cm³]




Accumulation



Depletion




Flat band voltage





If $\phi_s = \phi_m$, the flatband voltage is the zero bias voltage

Zero bias



$e\phi_m$
 Al 4.1 eV
 p+ poly 4.05 eV
 n+ poly 5.05 eV





Can be in accumulation or depletion depending on workfunctions



Weak Inversion

Majority carriers at $x = 0$ change from p to n

$n > p$
at the interface





Threshold voltage



Strong inversion: $n = N_A$ at $x = 0$, the semiconductor-oxide interface

Inversion

$n > N_A$ at $x = 0$, the semiconductor-oxide interface





MOS capacitor

In inversion, the charge in the inversion layer is:


$$Q = -C_{ox}(V_G - V_B - V_T)$$

Mobile charge per unit area


Specific capacitance F/m²



MOS capacitor



charge density (depletion)





$$-t_{ox} < x < 0 \quad \rho(x) = 0$$

$$0 < x < x_p \quad \rho(x) = -eN_A$$

$$x_p < x \quad \rho(x) = 0$$

electric field




$$0 < x < x_p$$

$$x_p < x$$

$$E(x) = \frac{-eN_A}{\epsilon_s} (x - x_p)$$

$$E(x) = 0$$

electric field (depletion)




E is decreased by
a factor of the
dielectric
constant



$$\epsilon_r = \frac{E_{vacuum}}{E_{dielectric}}$$

$$\epsilon_{ox} E_{ox} = \epsilon_s E_s$$

$$\frac{E_{ox}}{E_s} = \frac{\epsilon_s}{\epsilon_{ox}} \simeq 3$$



electric field



$$x < -t_{ox} \quad E(x) = 0$$

$$-t_{ox} < x < 0$$

$$E(x) = 0$$

$$E(x) = \frac{\epsilon_s}{\epsilon_{ox}} E(x=0^+) = \frac{eN_A x_p}{\epsilon_{ox}}$$


$$0 < x < x_p$$

$$E(x) = \frac{-eN_A}{\epsilon_s} (x - x_p)$$

$$x_p < x$$

$$E(x) = 0$$

electrostatic potential



$$x < -t_{ox}$$

$$\phi(x) = \phi_{gate}$$

$$-t_{ox} < x < 0$$

$$\phi(x) = \phi_p + \frac{eN_A x_p^2}{2\epsilon_s} + \frac{eN_A x_p}{\epsilon_{ox}}(-x)$$

$$0 < x < x_p$$

$$\phi(x) = \phi_p + \frac{eN_A}{2\epsilon_s} (x - x_p)^2$$

$$x_p < x$$

$$\phi(x) = \phi_p$$


(We still don't know x_p)

MOS Capacitor - Solving the Poisson Equation

The app below solves the Poisson equation to determine the band bending, the charge distribution, and the electric field in a MOS capacitor with a p-type substrate.

$\phi_m = 4.08$	eV	$\chi_s = 4.05$	eV
$t_{ox} = 3$	nm	$\epsilon_{ox} = 4$	
$E_g = 1.166 - 4.73E-4 * T^2 / (T + 636)$	eV	$\epsilon_{semi} = 12$	
$V = 0$ V		Submit	
<input type="button" value="-"/> <input type="button" value="+"/>		Si	Ge
		GaAs	

Band diagram




$$\begin{aligned} E_g &= 1.12 \text{ eV} & n_i &= 6.40e+9 \text{ 1/cm}^3 \\ E_s &= 1.57e+7 \text{ V/m} & V_s &= 0.831 \text{ V} \\ Q &= -0.00167 \text{ C/m}^2 & & \\ E_{ox} &= 4.70e+7 \text{ V/m} & V_{shoot} &= 0.0000221 \text{ V} \\ \phi_s &= 5.05 \text{ eV} & V_{fb} &= \phi_m - \phi_s = -0.972 \text{ V} \end{aligned}$$


From the depletion approximation:

$$\max(x_p) = 0.107 \mu\text{m} \quad V_T = 0.0292 \text{ V}$$

Charge density



Electric field



Band bending at inversion

$$n = N_A \text{ at threshold}$$


Far on the p side

$$n = \frac{n_i^2}{N_A} = N_c \exp\left(\frac{E_F - E_c}{k_B T}\right) \quad E_F - E_c = k_B T \ln\left(\frac{n_i^2}{N_A N_c}\right)$$

At the interface, $n = N_A$

$$N_A = N_c \exp\left(\frac{E_F - E_c}{k_B T}\right) \quad E_F - E_c = k_B T \ln\left(\frac{N_A}{N_c}\right)$$

The voltage between the semiconductor-oxide interface and the body



V_{IB} is the voltage between the interface and the body

$$eV_{IB} = k_B T \ln\left(\frac{N_A}{N_c}\right) - k_B T \ln\left(\frac{n_i^2}{N_A N_c}\right)$$


Strong inversion

$n_s = N_A$ at the semiconductor-oxide interface

$$eV_{IB} = k_B T \ln\left(\frac{N_A}{N_c}\right) - k_B T \ln\left(\frac{n_i^2}{N_A N_c}\right)$$

$$\ln(a) - \ln(b) = \ln\left(\frac{a}{b}\right)$$

$$eV_{IB} = k_B T \ln\left(\frac{N_A^2}{n_i^2}\right)$$



$$\ln(a^2) = 2 \ln(a)$$

$$eV_{IB} = 2k_B T \ln\left(\frac{N_A}{n_i}\right)$$

The depletion width remains constant in inversion.

Depletion width in inversion


$$V_{IB} = \frac{eN_A x_p^2}{2\epsilon}$$

$$eV_{IB} = 2k_B T \ln\left(\frac{N_A}{n_i}\right)$$

$$x_{p(\max)} = \sqrt{\frac{2\epsilon V_{IB}}{eN_A}} = 2\sqrt{\frac{\epsilon}{e^2 N_A}} k_B T \ln\left(\frac{N_A}{n_i}\right)$$

The depletion width remains constant in inversion.

Depletion width




Electric field at semi-oxide interface at strong inversion

$$eV_{IB}(\text{strong inversion}) = 2k_B T \ln\left(\frac{N_A}{n_i}\right)$$

$$E_s = 2 \frac{V_{IB}}{x_{p(\max)}} = \frac{2V_{IB}}{\sqrt{\frac{2\epsilon V_{IB}}{eN_A}}} = 2 \sqrt{\frac{N_A}{\epsilon} k_B T \ln\left(\frac{N_A}{n_i}\right)}$$

$V_{IB} = E_s x_p / 2 =$
area of the
triangle

$$E_{ox} = \frac{\epsilon}{\epsilon_{ox}} E_s = \frac{2\epsilon}{\epsilon_{ox}} 2 \sqrt{\frac{N_A}{\epsilon} k_B T \ln\left(\frac{N_A}{n_i}\right)}$$




Threshold voltage

$$V_T = E_{ox} (\text{strong inversion}) t_{ox} + V_{IB} (\text{strong inversion}) + V_{FB}$$

$$V_T = \frac{2\epsilon t_{ox}}{\epsilon_{ox}} \sqrt{\frac{N_A k_B T \ln\left(\frac{N_A}{n_i}\right)}{\epsilon}} + 2 \frac{k_B T}{e} \ln\left(\frac{N_A}{n_i}\right) + V_{FB}$$

$\frac{\epsilon t_{ox}}{\epsilon_{ox}} E_{inversion}$ V_{IB}





Small V_T requires a small t_{ox} and a large ϵ_{ox} .

MOS capacitance

$$C_{ox} = \frac{\epsilon_{ox}}{t_{ox}}$$

$$C_j = \frac{\epsilon}{x_p}$$



$$C = \left(\frac{1}{C_{ox}} + \frac{1}{C_j} \right)^{-1}$$



MOS Capacitor - Capacitance voltage

In capacitance-voltage profiling, the capacitance of a MOS capacitor is measured as a function of the bias voltage. The app below solves the Poisson equation to determine the charge-voltage and capacitance voltage characteristics of a MOS capacitor with a p-type substrate. This is the low-frequency result. At high frequencies, the charge at the oxide interface does not change fast enough and the characteristics take on another form.

$\phi_m = 4.08$	eV	$\chi_s = 4.05$	eV	
$t_{ox} = 3$	nm	$\epsilon_{ox} = 4$		
$E_g = 1.166 - 4.73E-4 * T * T / (T + 636)$	eV	$\epsilon_{semi} = 12$		
<input type="button" value="Submit"/> <input type="button" value="Si"/> <input type="button" value="Ge"/> <input type="button" value="GaAs"/>				
$N_c(300) = 2.78E19$		1/cm ³	$T = 300$	K
$N_v(300) = 9.84E18$		1/cm ³	$N_A = 1E17$	1/cm ³



$$E_g = 1.12 \text{ eV}$$

$$C_{ox} = \frac{\epsilon_{ox}}{t_{ox}} = 0.0118 \text{ F/m}^2$$




$$n_i = 6.40e+9 \text{ 1/cm}^3$$

$$V_T = 0.0292 \text{ V}$$


$$\phi_s = 5.05 \text{ eV}$$

$$V_{fb} = \phi_m - \phi_s = -0.972 \text{ V}$$

CCD devices



CCD devices



https://en.wikipedia.org/wiki/Charge-coupled_device#/media/File:CCD_charge_transfer_animation.gif