



# 10. MOSFETs

---


Dec. 5, 2018

# MOSFETs



n - channel

functions as a switch  
 ~ 1 billion /chip



p - channel


# Self-aligned fabrication

p-Si 100 wafer

Dry oxidation

SiO<sub>2</sub> gate oxide

p-Si




gate oxide

HfO<sub>2</sub>

SiO<sub>2</sub>

p-Si



photoresist

polysilicon

CVD:  $\text{SiH}_4$  @ 580 to 650 °C

$\text{SiO}_2/\text{HfO}_2$


TiN (CVD)

30–70  $\mu\Omega\cdot\text{cm}$  Conductive diffusion barrier


p-Si



# Implant



# Self-aligned fabrication





Spacer

PECVD  $\text{SiN}_x$


$\text{SiN}_x$

polysilicon  
gate

n+

n+

p-Si



# Spacer

Etch back to  
leave only  
sidewalls


$\text{SiN}_x$

polysilicon  
gate


n+

n+

p-Si




Implant




# Salicide (Self-aligned silicide)

Transition metal (Ti, Co, W) is deposited (CVD). During a high temperature step it reacts to a silicide ( $\text{TiSi}_2$ ). No silicide is formed on nitride or oxide.






Master Thesis:  
**Modeling and Characterization of  
Semiconductor Devices at Cryogenic  
Temperatures**



MOSFET in TCAD

# CMOS


NMOS is n-channel so it should be in a p-well




**Figure 26.11** Deep submicron CMOS: 200 nm gate length, 5 nm gate oxide, 70 nm junction depth;  $n^+$  poly for NMOS and  $p^+$  poly for PMOS. Shallow trench isolation on epitaxial  $n^+/p^+$  wafer

Source: Fransila


# MOS capacitor




# Accumulation



no depletion layer






$\rho \times 10^{-15}$   
[C/cm<sup>3</sup>]



$N_A$





# Accumulation




# Depletion

---




# Flat band voltage





If  $\phi_s = \phi_m$ , the flatband voltage is the zero bias voltage

# Zero bias



$e\phi_m$   
 Al 4.1 eV  
 p+ poly 4.05 eV  
 n+ poly 5.05 eV





Can be in accumulation or depletion depending on workfunctions



# Weak Inversion

Majority carriers at  $x = 0$  change from p to n

$n > p$   
at the interface





# Threshold voltage



**Strong inversion:**  $n = N_A$  at  $x = 0$ , the semiconductor-oxide interface

# Inversion

$n > N_A$  at  $x = 0$ , the semiconductor-oxide interface





# MOS capacitor

In inversion, the charge in the inversion layer is:

$$Q = -C_{\text{ox}}(V_G - V_B - V_T)$$


Mobile charge per unit area

Specific capacitance F/m<sup>2</sup>






# MOS capacitor



# charge density (depletion)

---





$$-t_{ox} < x < 0 \quad \rho(x) = 0$$

$$0 < x < x_p \quad \rho(x) = -eN_A$$

$$x_p < x \quad \rho(x) = 0$$

# electric field




$$0 < x < x_p$$

$$x_p < x$$

$$E(x) = \frac{-eN_A}{\epsilon_s} (x - x_p)$$

$$E(x) = 0$$

# electric field (depletion)




$E$  is decreased by a factor of the dielectric constant


$$\epsilon_r = \frac{E_{vacuum}}{E_{dielectric}}$$

$$\epsilon_{ox} E_{ox} = \epsilon_s E_s$$

$$\frac{E_{ox}}{E_s} = \frac{\epsilon_s}{\epsilon_{ox}} \approx 3$$



# electric field




$$E(x) = 0$$

$$E(x) = \frac{\epsilon_s}{\epsilon_{ox}} E(x = 0^+) = \frac{eN_A x_p}{\epsilon_{ox}}$$

$$E(x) = \frac{-eN_A}{\epsilon_s} (x - x_p)$$

$$E(x) = 0$$

# electrostatic potential



$$x < -t_{ox} \quad \phi(x) = \phi_{gate}$$

$$-t_{ox} < x < 0 \quad \phi(x) = \phi_p + \frac{eN_A x_p^2}{2\epsilon_s} + \frac{eN_A x_p}{\epsilon_{ox}} (-x)$$

$$0 < x < x_p \quad \phi(x) = \phi_p + \frac{eN_A}{2\epsilon_s} (x - x_p)^2$$

$$x_p < x \quad \phi(x) = \phi_p$$

(We still don't know  $x_p$ )


# MOS Capacitor - Solving the Poisson Equation

The app below solves the Poisson equation to determine the band bending, the charge distribution, and the electric field in a MOS capacitor with a p-type substrate.

$\phi_m = 4.08$  eV     $\chi_s = 4.05$  eV  
 $t_{ox} = 3$  nm     $\epsilon_{ox} = 4$   
 $E_g = 1.166 - 4.73E-4 * T * T / (T + 636)$  eV     $\epsilon_{semi} = 12$   
 $N_c(300) = 2.78E19$  1/cm<sup>3</sup>     $T = 300$  K  
 $N_v(300) = 9.84E18$  1/cm<sup>3</sup>     $N_A = 1E17$  1/cm<sup>3</sup>  
 $V = 0$  V


Band diagram




$E_g = 1.12$  eV     $n_i = 6.40e+9$  1/cm<sup>3</sup>  
 $E_s = 1.57e+7$  V/m     $V_s = 0.831$  V  
 $Q = -0.00167$  C/m<sup>2</sup>  
 $E_{ox} = 4.70e+7$  V/m     $V_{shoot} = 0.0000221$  V  
 $\phi_s = 5.05$  eV     $V_{fb} = \phi_m - \phi_s = -0.972$  V

From the depletion approximation:  
 $\max(x_p) = 0.107$  μm     $V_T = 0.0292$  V

Charge density



Electric field



# Band bending at inversion

$$n = N_A \text{ at threshold}$$

Far on the p side


$$n = \frac{n_i^2}{N_A} = N_c \exp\left(\frac{E_F - E_c}{k_B T}\right) \quad E_F - E_c = k_B T \ln\left(\frac{n_i^2}{N_A N_c}\right)$$

At the interface,  $n = N_A$

$$N_A = N_c \exp\left(\frac{E_F - E_c}{k_B T}\right) \quad E_F - E_c = k_B T \ln\left(\frac{N_A}{N_c}\right)$$

The voltage between the semiconductor-oxide interface and the body

$$eV_{IB} = k_B T \ln\left(\frac{N_A}{N_c}\right) - k_B T \ln\left(\frac{n_i^2}{N_A N_c}\right)$$



$V_{IB}$  is the voltage between the interface and the body



# Strong inversion

---

$n_s = N_A$  at the semiconductor-oxide interface


$$eV_{IB} = k_B T \ln\left(\frac{N_A}{N_c}\right) - k_B T \ln\left(\frac{n_i^2}{N_A N_c}\right)$$

$$\ln(a) - \ln(b) = \ln\left(\frac{a}{b}\right)$$

$$eV_{IB} = k_B T \ln\left(\frac{N_A^2}{n_i^2}\right)$$

$$\ln(a^2) = 2 \ln(a)$$

$$eV_{IB} = 2k_B T \ln\left(\frac{N_A}{n_i}\right)$$



The depletion width remains constant in inversion.

# Depletion width in inversion

---


$$V_{IB} = \frac{eN_A x_p^2}{2\varepsilon}$$

$$eV_{IB} = 2k_B T \ln\left(\frac{N_A}{n_i}\right)$$

$$x_{p(\max)} = \sqrt{\frac{2\varepsilon V_{IB}}{eN_A}} = 2\sqrt{\frac{\varepsilon}{e^2 N_A} k_B T \ln\left(\frac{N_A}{n_i}\right)}$$

The depletion width remains constant in inversion.

# Depletion width




# Electric field at semi-oxide interface at strong inversion

$$eV_{IB}(\text{strong inversion}) = 2k_B T \ln\left(\frac{N_A}{n_i}\right)$$

$$E_s = 2 \frac{V_{IB}}{x_{p(\max)}} = \frac{2V_{IB}}{\sqrt{\frac{2\epsilon V_{IB}}{eN_A}}} = 2 \sqrt{\frac{N_A}{\epsilon} k_B T \ln\left(\frac{N_A}{n_i}\right)}$$

$$E_{ox} = \frac{\epsilon}{\epsilon_{ox}} E_s = \frac{2\epsilon}{\epsilon_{ox}} \sqrt{\frac{N_A}{\epsilon} k_B T \ln\left(\frac{N_A}{n_i}\right)}$$

$V_{IB} = E_s x_p / 2 =$   
area of the




# Threshold voltage

$$V_T = E_{ox}(\text{strong inversion})t_{ox} + V_{IB}(\text{strong inversion}) + V_{FB}$$

$$V_T = \frac{2\epsilon t_{ox}}{\epsilon_{ox}} \sqrt{\frac{N_A k_B T \ln\left(\frac{N_A}{n_i}\right)}{\epsilon}} + 2 \frac{k_B T}{e} \ln\left(\frac{N_A}{n_i}\right) + V_{FB}$$

$\frac{\epsilon t_{ox}}{\epsilon_{ox}} E_{inversion}$                        $V_{IB}$







Small  $V_T$  requires a small  $t_{ox}$  and a large  $\epsilon_{ox}$ .

# MOS capacitance

$$C_{ox} = \frac{\epsilon_{ox}}{t_{ox}} \quad C_j = \frac{\epsilon}{x_p}$$

$$C = \left( \frac{1}{C_{ox}} + \frac{1}{C_j} \right)^{-1}$$




## MOS Capacitor - Capacitance voltage

In capacitance-voltage profiling, the capacitance of a MOS capacitor is measured as a function of the bias voltage. The app below solves the Poisson equation to determine the charge-voltage and capacitance voltage characteristics of a MOS capacitor with a p-type substrate. This is the low-frequency result. At high frequencies, the charge at the oxide interface does not change fast enough and the characteristics take on another form.

$\phi_m =$ <input type="text" value="4.08"/> eV	$\chi_s =$ <input type="text" value="4.05"/> eV		
$t_{ox} =$ <input type="text" value="3"/> nm	$\epsilon_{ox} =$ <input type="text" value="4"/>	$N_c(300) =$ <input type="text" value="2.78E19"/> 1/cm <sup>3</sup>	$T =$ <input type="text" value="300"/> K
$E_g =$ <input type="text" value="1.166-4.73E-4*T*T/(T+636)"/> eV	$\epsilon_{semi} =$ <input type="text" value="12"/>	$N_v(300) =$ <input type="text" value="9.84E18"/> 1/cm <sup>3</sup>	$N_A =$ <input type="text" value="1E17"/> 1/cm <sup>3</sup>
<input type="button" value="Submit"/>	<input type="button" value="Si"/>	<input type="button" value="Ge"/>	<input type="button" value="GaAs"/>

Q - V




$$E_g = 1.12 \text{ eV}$$

$$C_{ox} = \frac{\epsilon_{ox}}{t_{ox}} = 0.0118 \text{ F/m}^2$$

$$n_i = 6.40e9 \text{ 1/cm}^3$$

$$V_T = 0.0292 \text{ V}$$

C - V




$$\phi_s = 5.05 \text{ eV}$$



$$V_{fb} = \phi_m - \phi_s = -0.972 \text{ V}$$

# CCD devices

---



- fixed acceptors
- ⊖ mobile electrons





# CCD devices

---

